


Spare Parts  
**Metering valve ST-161 panel**  
 Item-No. 20 0161 510



Pos.	Item-No.	Description	Pos.	Item-No.	Description
1	04 0003 598	Hose clip	14	05 0000 565	O- ring 17x1,5 EPDM
2	04 0003 555	Check valve piston	15	02 0001 678	Plastic display
3	05 0000 265	O-ring 2,9x1,78	16	04 0000 200	Nut
4	06 0001 100	Spring	17	04 0003 590	Adaptor ST-161
5	04 0003 558	Screw plug	18	04 0004 245	safety disc
6	05 0000 301	O-ring 10.82 x 1.78			
7	04 0003 563	Supporting ring			
8	04 0003 603	Coupling nut ST-161			
9	04 0003 602	Piston ST-161			
10	02 0001 657	Adjustment button			
11	04 0003 564	Nozzle ST-161			
12	05 0000 360	O-Ring 7x1			
13	05 0000 440	o-ring			

### Repair-Kits

Pos.	Item-No.	Description	Pos.	Item-No.	Description
*	20 0161 490	Repair Kit ST-161			