


SPARE PART LIST VARAOSALISTA

FINN-POWER
P16HP

ver. 1.5



Released/Julkaistu 9/2015




P16 HP 1.5 SPARE PART KITS SPARE_PART_KITS

F/N	Part Number	Rev	Description	Qty
1	MD-P16A		MASTER DIE KIT	1
2	SK-P16A		SEAL KIT	1

P16 HP 1.5


EQUIPMENT

710146



P16 HP 1.5 EQUIPMENT 710146

F/N	Part Number	Rev	Description	Qty
1	418305		PUMP	1
2	703949		BASE	1
3	164910		BOX	1
4	031229		HEX SOCKET-HEAD SCREW	2
5	301726		HOLD-DOWN CLAMP	1
6	031226		HEX SOCKET-HEAD SCREW	1
7	033304		WASHER	4
8	0540136		HANDLE	1
9	710272		PIPE	1
10	419730		ELBOW FITTING	1
11	419728		STRAIGHT CONNECTOR	1
12	419727		STRAIGHT CONNECTOR	1
13	031238		HEX SOCKET-HEAD SCREW	2
14	031228		HEX SOCKET-HEAD SCREW	2
15	031217		HEX SOCKET-HEAD SCREW	2
16	033004		HEXAGONAL NUT	4
17	032402		SLOT-HEADED SCREW	2
18	419710		BOTTOM PLATE	1
19	031310		HEX SOCKET-HEAD SCREW	4
20	003333		STICKER	1
21	003328		STICKER	1
22	003199		STICKER	1
23	704253		STICKER	1
24	706591		RIVET NUT	4




P16 HP 1.5 CRIMPING UNIT 63265

F/N	Part Number	Rev	Description	Qty
1	131161	B	CYLINDER	1
2	131162	F	PISTON	1
3	141193	0	FRONT FLANGE	1
4	301725	0	MASTER DIE SET	1
5	053092	0	PRESSURE SPRING	6
6	054169	0	FLEXIBLE PUSH-BUTTON	8
7	031241	0	HEX SOCKET-HEAD SCREW	14
8	053089	0	PRESSURE SPRING	6
9	0480148	0	O-RING	1
10	048015	0	O-RING	1
11	048632	0	SUPPORTING RING	1
12	048624	0	SUPPORTING RING	1
13	053093	0	PRESSURE SPRING	8
14	031242	0	HEX SOCKET-HEAD SCREW	4

P16 HP 1.5

CONTROL DEVICE

691561




P16 HP 1.5 CONTROL DEVICE 691561

F/N	Part Number	Rev	Description	Qty
1	702709	A	FRAME	1
2	111576	A	SPINDLE	1
3	702711	A	ADJUSTING KNOB	1
4	111578	0	BACK STOP	1
5	0312132	0	HEX SOCKET-HEAD SCREW	1
6	033003	0	HEXAGONAL NUT	2
7	033029	0	HEXAGONAL NUT	1
8	053019	0	PRESSURE SPRING	1
10	424778	0	CLAMP SCREW	1
11	705700	0	O-RING	1

P16 HP 1.5

ELECTRICAL COMPON.

676004



P16 HP 1.5 ELECTRICAL COMPON. 676004

F/N	Part Number	Rev	Description	Qty
D1	061017		LED	1
R1	064053		RESISTANCE	1
GB1	072260		BATTERY BOX	1
	072261		BATTERY	1
S1/SL1	092004		PUSH-BUTTON	1

P16 HP 1.5

HAND PUMP

P392E043


ENERPAC 
POWERFUL SOLUTIONS. GLOBAL FORCE.

Repair Parts Sheet

P392E043
Hand Pump

L2575 Rev. A 06/15

For Date Codes Beginning with the Letter "B"





P16 HP 1.5 HAND PUMP P392E043

F/N	Part Number	Rev	Description	Qty
1			Pump Unit Assembly	1
2	B1135517		Square Ring Seal	1
3	DA3729900		Filter Assembly	1
4	E012524025		Reservoir	1
5	E012524149		Tie Rod	1
6	B1246503		O-Ring	1
7	DC362020		End Cap	1
8	DA10722108		Washer	1
9	B1009503		O-Ring	1
10	CL341055		Acorn Nut	1
11	CT2588900		Filter Plug Assembly	1

P16 HP 1.5

PUMP UNIT ASSEMBLY

PUMP UNIT ASSEMBLY



P16 HP 1.5 PUMP UNIT ASSEMBLY PUMP UNIT ASSEMBLY

F/N	Part Number	Rev	Description	Qty
2	CN815006		Pipe Plug	2
3	DA1176210		Conical Spring	2
4	B1009016		5/16" Ball	3
5	B1006016		7/32" Ball	1
6	DA6301900		Release Valve Spindle	1
7	CU921028		Truss Head Machine Screw	1
8	B1007503		O-Ring	1
9	E012524900-1		Plunger Assembly (Includes 12 and 13)	1
10	DA8802900SR		High Pressure Relief Valve Assy.	1
12	B1009803		O-Ring	1
13	B1009564		Back-Up Washer	1
14	B1234503		O-Ring	1
17	DA5493900		Low Pressure Relief Assy	1
19	E012524900-2		Beam/Handle	1
20	DC106061SR		Beam Pin	1
21	DA1177349		Retaining Ring	2
22	CR214031		Beam Pin	1
23	CM927061		Locking Pin	1
24	Y267110		Spring	1
25	CM928044		Push-on Ring	1
50	DA3702020		Spring Cap	2

P16 HP 1.5 P16 HP 1.5 TOC

F/N	Part Number	Rev	Description	Qty
	SPARE_PART_KITS		SPARE PART KITS	
	710146		EQUIPMENT	
	63265		CRIMPING UNIT	
	676004		ELECTRICAL COMPON.	
	691561		CONTROL DEVICE	
	P392E043		HAND PUMP	