


|                 |
|-----------------|
| Spare Parts     |
| Lance ST-146    |
| Item-No. 514529 |



| Pos. | Item-No.  | Description                      |
|------|-----------|----------------------------------|
| 1    | 200146500 | Connector                        |
| 2    | 020001958 | Adapter part ST-9.1 (2) black    |
| 3    | 040001281 | Socket G1/4 IG                   |
| 4    | 020001972 | Half shell left ST-9.1 black     |
| 5    | 020001975 | Half shell ST-9.1 black          |
| 6    | 020001970 | Half shell right ST-9.1 black    |
| 7    | 020001980 | Connector ST-9.1 black           |
| 8    | 020001990 | Ending part ST-9.1 black         |
| 9    | 070010008 | Nozzle pipe                      |
| 10   | 010000045 | Coupling nut protection          |
| 11   | 010000041 | Connecting part M18x1,5 w. flute |
| 12   | 050000125 | O-ring 10x2,2 NBR 70 Shore       |

## Repair-Kits

| Pos. | Item-No. | Description | Pos. | Item-No. | Description |
|------|----------|-------------|------|----------|-------------|
| .    |          |             |      |          |             |